

APPLICATION GUIDANCE

RIGHTFINISH

SKIMCOAT

Thin Coat Plaster

Polish up with trowel

Wet the trowel

Closing in

Apply first coat

Apply second coat

For the right consistency gradually add 25 kg of SKIMCOAT to 11,5 - 12 ltrs of clean water.

White Plaster

Cover More
Approx.
11 m²/bag
(2 mm thick)

Easy to Apply



Site practice may vary the recommended time.

rightfinish.co.uk